


# **ALLIED**

## **995 LOADER**



**MODELS 995 TSL, S995 TSL**

## **Assembly, Operator's and Parts Manual**

**Part No. P3792**

03/00

## **WARRANTY REGISTRATION AND POLICY**

Buhler Manufacturing products are warranted for a period of twelve (12) months from original date of purchase, by original purchaser, to be free from defects in material and workmanship under correct, normal agricultural use and proper applications.

Buhler Manufacturing's obligations under this warranty shall be limited to the repair or exchange, at Buhler Manufacturing's option, of any Buhler Manufacturing product or part which proves to be defective as provided. Buhler Manufacturing reserves the right to either inspect the product at the buyer's location or have it returned to the factory for inspection.

The above warranty does not extend to goods damaged or subject to accident, abuse or misuse after shipment from Buhler Manufacturing's factory, nor to goods altered or repaired by anyone other than an authorized Buhler Manufacturing representative.

Buhler Manufacturing makes no Express Warranties other than those which are specifically described. Any description of goods, including any references and specifications in catalogues, circulars and other written material published is for the sole purpose of identifying goods and shall conform to such descriptions. Any sample or model is for illustrative purposes only and does not create an Express Warranty that the goods conform to sample or model shown.

The purchaser is solely responsible for determining suitability of goods sold. This warranty is expressly in lieu of all other warranties expressed or implied. Buhler Manufacturing will in no event be liable for any incidental or consequential damages whatsoever, nor for any sum in excess of the price received for the goods for which liability is claimed.

### **WARRANTY CLAIMS:**

Warranty requests must be prepared on Buhler Manufacturing Warranty Claim Forms with all requested information properly completed. Warranty Claims must be submitted within a thirty (30) day period from date of failure repair.

### **WARRANTY LABOR:**

Any labor subject to warranty **must** be authorized by Buhler Manufacturing. The labor rate for replacing defective parts, where applicable, will be credited at a rate determined by the Company, Buhler Manufacturing.

### **IMPORTANT FACTS:**

**Buckets and Bucket Tines Carry No Warranty**  
**Bent Spears Carry No Warranty**  
**Snowblower Fan Shafts Carry No Warranty**  
**Mower Blades Carry No Warranty**  
**Portable Auger Parts Have Two (2) Year Warranty**  
**Loader Parts Have Two (2) Year Warranty**

**995**  
**Hydraulic Farm Loader**

**Operator's Manual**  
Table of Contents

<b>Section</b>	<b>Description</b>	<b>Page</b>
	Warranty Registration and Policy .....	
	Table of Contents .....	
<b>Introduction and Identification</b>	Loader Specification Chart .....	2
	Torque Chart .....	2
	Pre-delivery Check List .....	3
	Loader Identification Diagram .....	3
	Hydraulic Hose Kit Identification Diagrams .....	4
<b>Safety and Pre-use Information</b>	Important Precautions .....	5
	Safety .....	6
	Safety Decals .....	7
	Lubrication and Decals Location Diagram .....	8
<b>Operating Information</b>	General Instructions and Information .....	9
	Operating Suggestions for Loading .....	10
	Operating Suggestions for Backfilling .....	11
	Attaching the Loader to Your Tractor .....	12
	Removing the Loader from Your Tractor .....	14
	Operation and Maintenance .....	16
	Trouble Shooting .....	17
<b>Assembly and Parts Information</b>	Sub-frame Diagram .....	18
	Mainframe Diagram .....	20
	Hydraulic Plumbing Diagram .....	22
	Hydraulic Cylinder Assembly .....	24



**IMPORTANT**

**PLEASE READ AND UNDERSTAND THIS MANUAL BEFORE OPERATING LOADER.**

## LOADER SPECIFICATION SHEET

(PER ASAE S301.2)


MARCH 20, 2000

MODEL NUMBER: 995 TSL REGULAR  
 MOUNTING HEIGHT: 52.0 (NOMINAL)  
 TYPICAL RANGE: 48.0 TO 56.0

CYLINDER SPECIFICATIONS [INCHES]

CYLINDER	BORE	ROD	STROKE	EXTENDED LENGTH	RETRACTED LENGTH
BUCKET	3.00	1.75	24.75	86.50	61.75
LIFT	3.50	2.00	32.50	85.00	52.50

- A) MAXIMUM LIFT HEIGHT TO PIVOT POINT (FULL HEIGHT): 181.0
  - B) MAXIMUM LIFT HEIGHT UNDER LEVEL BUCKET: 172.0
  - C) CLEARANCE WITH BUCKET DUMPED: 152.0
  - D) REACH AT MAXIMUM LIFT HEIGHT: 25.0
  - E) TSL MAX DUMP ANGLE(FULL HEIGHT): 70°
  - E1) TSL MAX DUMP ANGLE AT GROUND: 90°
  - G) BUCKET ROLLBACK ANGLE (GROUND): 36°
  - G1) TSL BUCKET ROLLBACK ANGLE: 50°
  - H) DIGGING DEPTH: 9.0
  - J) OVERALL HEIGHT IN CARRY POSITION: 102.0
- ESTIMATED BREAKOUT FORCE: 6600 LBS  
 ESTIMATED LIFT CAPACITY: 4075 LBS



**NOTES:**

- 1) ESTIMATED VALUES ASSUME 2500 PSI LIFT CYLINDER PRESSURE.
- 2) BREAKOUT FORCE ESTIMATED AS PER ASAE S301.2-4.1.2. (NET PAYLOAD APPLIED AT CUTTING EDGE)
- 3) LIFT CAPACITY ESTIMATED AS PER ASAE S301.2-4.1.1. (PAYLOAD APPLIED AT BUCKET MIDPOINT)
- 4) MAIN PIVOT PIN:  $\phi 1.50$ . ALL OTHER PINS:  $\phi 1.25$

## Torque Specifications

Recommended Torque in Foot Pounds (ft-lbs) & Newton Meters (NM)\*

		Standard						
Bolt Diameter (Inches)	Wrench Size (Inches)	Bolt Head						
		Grade 2 (ft-lbs) (NM)		Grade 5 (ft-lbs) (NM)		Grade 8 (ft-lbs) (NM)		
0.250	1/4	7/16	6	7	8	11	12	16
0.313	5/16	1/2	11	15	17	23	25	33
0.375	3/8	9/16	20	27	31	42	44	60
0.438	7/16	5/8	32	43	49	66	70	95
0.500	1/2	3/4	49	66	76	103	106	144
0.563	9/16	7/8	70	95	109	148	153	207
0.625	5/8	15/16	97	131	150	203	212	287
0.750	3/4	1 1/8	144	195	266	360	376	509
0.875	7/8	1 5/16	166	225	430	583	606	821
1.000	1	1 1/2	250	339	644	873	909	1232
1.125	1 1/8	1 11/16	354	480	795	1077	1288	1745
1.250	1 1/4	1 7/8	500	678	1120	1518	1817	2462
1.375	1 3/8	2 1/16	655	887	1470	1992	2382	3228
1.500	1 1/2	2 1/4	870	1179	1950	2642	3161	4283

		Metric					
Bolt Dia. (mm)	Wrench Size (mm)	Bolt Head					
		Class 4.6 (ft-lbs) (NM)		Class 8.8 (ft-lbs) (NM)		Class 9.8 (ft-lbs) (NM)	
8	13	7.3	10			21.1	29
10	16	14.5	20			42	57
12	18	25	34	74	100	73	99
14	21	40	54	118	160	116	157
16	24	62	84	167	226	181	245
20	30	122	165	325	440		
22	33			443	600		
24	36	211	286	563	763		
27	41			821	1112		
30	46	418	566	1119	1516		

\*Use 80% of the specified torque value for plated or lubricated fasteners.

## Pre-delivery Check List


Before delivering this equipment please complete the following check list.

- 1. The loader has been installed using the appropriate mounting kit for the tractor and loader.
- 2. The hydraulic system installed is appropriate for the tractor and loader
- 3. The loader is properly installed.
- 4. All bolts are tightened to the torque specifications shown in the torque chart.
- 5. All safety decals are readable.
- 6. The loader has been tested and operates properly.
- 7. The operator's manual has been delivered to the owner who has been instructed on the safe and proper use of the loader.

Dealer's Signature \_\_\_\_\_

This check list is to remain in this Owner's Manual and is the responsibility of the dealer to complete it before delivery to the customer.

## Loader Identification Diagram (HSL Model Shown)




For further details refer to Loader Mainframe and Subframe diagrams.

## Hydraulic (Hose Kit) Identification Diagrams

### Hose Kit "A"

Loader Powered by the tractor remotes.


Consists of four hoses leading from loader tubing to tractor remote couplers



### Hose Kit "B"

Loader operated by an external OC or CC valve that is powered from the tractor remotes


Consists of 4 hoses leading from loader tubing to external mounted valve and 2 hoses from valve to tractor couplers. Use the valve type shown with hose kit "B".



### Hose Kit "C"



Loader operated by an external valve that is plumbed into the tractor hydraulic system.

Consists of 4 hoses leading from loader tubing to external mounted valve plus the necessary fittings, hoses and adapter blocks (if necessary) to tap into tractor hydraulic system. Use valve type shown with hose kit "C".




## Safety

- Never work beneath raised loader unless it is securely supported. The following are instructions for the Lift Lock Supports;



- Do not pivot or turn tractor with bucket raised, except at a minimum speed. Always make allowance for length of loader when making turns.
- Never leave tractor unattended while the bucket is raised. Always lower bucket to the ground and shut off before leaving tractor seat.
- Do not walk under raised bucket.
- Never operate loader while operator is not seated in the driver's seat on the tractor.
- Keep tractor on solid ground. Loose fill, rocks and holes can be dangerous for loader operation or movement.
- Never operate a loader with frayed or damaged hoses or leaking fittings.
- Add ballast as required to ensure 25% of gross vehicle weight is transferred to the rear axle.

- Space rear tires as recommended by tractor manufacturer. Maximize width for high lift applications.
- Do not raise bucket to extreme heights while tractor is on an incline. Carry loader low for safety. Note in above illustration how load center moves out when bucket is raised on a slope. Be alert for terrain changes and adjust bucket accordingly. Keep bucket low, no more than one foot high, as long as possible.
- Note: A pivoting front axle acts like a three-wheeled tractor until the stops hit the axle.



- If lift cylinders are used to raise front wheels of tractor for service, place blocks under tractor before working around front end.


**THIS SAFETY ALERT SYMBOL MEANS:  
 ATTENTION!  
 BECOME ALERT!  
 YOUR SAFETY IS INVOLVED!**





# Important Precautions

**⚠ DANGER**



**ELECTROCUTION HAZARD**  
To prevent serious injury or death:

Stay away from power lines and cables.  
Electrocution can occur with or without direct contact.

**⚠ WARNING**



**FALLING HAZARD**  
To prevent serious injury or death:

Do not lift, carry or allow anyone to ride on or work from any portion of loader.


**⚠ WARNING**



**CRUSHING HAZARD**  
To prevent serious injury or death:

Do not handle round bales or other shiftable objects unless loader is equipped with an attachment designed for this purpose.  
Do not handle loose loads that are not secured.  
Do not lift load higher than necessary.


**⚠ WARNING**



**HIGH PRESSURE FLUID**  
To prevent serious injury or death:

Relieve pressure on system before repairing or adjusting or disconnecting.  
Wear proper hand and eye protection when searching for leaks. Use wood or cardboard instead of hands.  
Keep all components in good repair.  
If hydraulic fluid penetrates skin, obtain medical treatment IMMEDIATELY.

**⚠ WARNING**



**ROLL-OVER HAZARD**  
To prevent serious injury or death:

Move and turn tractor at low speed.  
Carry load no higher than necessary to clear the ground when transporting.  
Add wheel ballast or rear weight for stability.  
Move wheels to widest possible settings to increase stability.  
It is recommended the tractor be equipped with a rollover protective structure (ROPS).

**⚠ WARNING**



**CRUSHING HAZARD**  
To prevent serious injury or death:

Do not allow bystanders in loader work area.  
Lower loader to the ground before leaving seat.  
Do not walk or work under raised loader. For servicing, refer to operator's manual.  
Read and understand operator's manual before operating loader.

## Safety Decals

These decals are located as shown on the Decal Location diagram and the Sub-Frame Assembly diagram.


 **WARNING**



**OVERHEAD HAZARD**  
*STAY AWAY FROM UNDER LIFT  
ARMS AND BUCKET*

To prevent serious injury or death:

1. Do not stand or work under raised loader, unless supported.
2. Support bucket and lift arms before working under loader.
3. Lower loader to the ground before leaving seat.


 **CAUTION**

1. Read Operator's Manual before operating.
2. Move and turn tractor at low speed.
3. Carry loader arms at a low position during transport.
4. Lower loader arms, stop engine and lock brakes before leaving operator seat.
5. Do not stand or work under raised loader, unless properly supported.
6. Add recommended wheel ballast or rear weight for stability.
7. Move wheels to widest recommended settings to increase stability.
8. Do not handle large round bales or other shiftable objects unless loader is equipped with a grapple fork.
9. Do not use loader to move or carry people.
10. Stay away from power lines. Electrocutation can occur without direct contact.
11. Review safety instructions annually.

# Lubrication and Decal Location Diagram

Lubricate tractor hydraulic unit as indicated in tractor Operator's Manual. Keep bushings on lift arm pivots and cylinders well lubricated. Use high-grade lithium grease every 8 hours of operation.

**NOTE:** Frequent greasing will prevent contaminants from migrating between the pins and bushings.



 Symbol indicating grease after every 8 hours of operation

## General Instructions and Information

As with any piece of equipment, the care with which your loader is operated and maintained will greatly affect its life and the safety of the people using it.

1. Keep all pivots well lubricated for longer bushing life. Inspect every 500 hours of operation for wear.
2. Periodically check all bolts for tightness. If any bolt is damaged, replace it with a bolt of equivalent grade or strength.
3. Follow the recommendations of the tractor manufacturer in regards to the quantity of oil used.
4. Check oil level frequently to ensure the system is full.
5. When making an oil check, be sure lift cylinders are retracted.
6. Before operating the loader, particularly if the loader is left standing for any length of time, check the hydraulic system and oil level.
7. When installing hydraulics, follow the circuit carefully. See hydraulic hook-up section and make sure the hoses do not contact any hot manifolds or sharp edges on tractor. After assembly, raise the loader slowly and check to make sure that the hoses do not bind in all positions.



### CAUTION

The pressure of the relief and open center valves is set at the factory. Do not tamper with the setting, serious injury to the operator or damage to the loader or tractor hydraulics may occur. Warranty will be void if the loader is operated above recommended pressure.

9. When servicing any hydraulic components, care must be taken to prevent any foreign matter from entering the system.
10. Do not neglect oil leaks. Leaks affect loader operation, are dangerous and can result in personal injury or damage to the hydraulic system.
11. Never leave the cylinder shafts exposed when loader is not in use.
12. Worn or damaged components should be replaced as soon as possible with only the manufacturer's recommended component or equivalent.

# Operation and Maintenance

## GENERAL

Refer to tractor Operator's Manual for Operating information on the tractor's hydraulic system.

Hydraulic systems using auxiliary valves should have them located for easy reach from the tractor seat. Hoses should be connected in such a manner that pushing forward on valve handles lowers the boom or dumps the bucket.

**CAUTION:** Always connect boom hoses to float section.

Weight added to rear of tractor provides better traction and an easier, more efficient loader operation. Extra weight, along with widening the rear wheels, reduces the risk of roll-over.





**WARNING**

The smaller the tractor is, the easier it will roll. We recommend that weight be added to rear tires with liquid or by the installation of rear wheel weights. Where additional weight is required, a counterweight box can be fabricated for tractors with three-point hitches.

Extra weight can also be added by the use of a heavy implement mounted to the three-point hitch.

A roll-over protective structure is also recommended.



In cold weather, operate the tractor's engine at idle speed until the hydraulic fluid is warmed up. High engine speed when the hydraulic fluid is cold will cause the pump to wear prematurely.


Under normal conditions, operate the tractor's engine at ½ throttle. Shift the tractor into a low gear before entering a pile of material to minimize strain on loader arms.

## Operating Suggestions for Loading


When handling heavy loads, be sure to lower lift arms slowly. This is known as feathering the hydraulic lever. If load is lowered too fast and stopped suddenly, excessive shock loads are created which can damage loader or tractor.

When loading bucket, drive straight into material. Attempting to turn tractor while loading bucket can cause damage to both the loader and tractor.

Come in level:




NOTE: Bottom surface of bucket is parallel to line on motion




Work both levers back to direct pressure to both cylinders.

Combined action of lift and bucket cylinders increases loading efficiency.


**DO THIS!**




**NOT THIS!**



A straight bottom offers more resistance to lift.




To increase loading efficiency, minimize angle of turn and length to run between pile and spreader.




Leave material which drifts over side of bucket for final clean-up.

## Operating Suggestions For Backfilling

DO THIS!



When backfilling approach pile with a flat bucket. Leave dirt in bucket. Dumping on each pass wastes time.



Backgrade work surface with a loaded bucket. Release all pressure on lift cylinders so full weight of bucket is scraping ground. Use heel of bucket.

NOT THIS!



**WARNING!**

**DO NOT USE LOADER  
AS BATTERING RAM!**

**SAFETY: FIRST, LAST, ALWAYS**




DO NOT use bucket in dumped position for bulldozing. This will only impose severe shock loading on the bucket cylinders and make it more difficult to maintain a level grade.

## Attaching the Loader to Your Tractor

1. Position the tractor as centrally as possible and drive, using lowest gear possible, into the loader frame until hoses can be connected.
2. Couple up the hydraulic hose lines to the loader or tractor valve ensuring proper function (see Operator and Maintenance Section)

**NOTE: When mounting the loader for the first time, slowly work the cylinders back and forth, so that most of the air is removed. Loosen the bolts on the hooks so that they can be moved. Also, check that the nuts in the rear of the subframes are in line with the holes.**

3. On some tractors, the lift cylinders may have to be extended slightly, so that the subframes can clear the front axle. Do not extend the cylinders more than is required.




**IMPORTANT! On self leveling loaders, the bucket will dump at the same time the loader is raised. Therefore, operate both hydraulic levers together.**

4. Drive the tractor ahead until the subframe is past the front axle and the front hook is close to mounting boss.




**WARNING! Check front grill clearance during installation to avoid tractor damage.**



5. Retract or extend the lift cylinders to line up the front hook with the mounting boss.




**IMPORTANT! On self leveling loaders, the bucket will roll back at the same time the loader is lowered. Therefore, operate both hydraulic levers together.**






## Attaching the Loader to Your Tractor (Continued)

6. When the hook is lined up, dump or roll back the bucket to lower or raise the subframe upright to align with the mounting boot.




7. Continue to drive the tractor forward until the subframe uprights are seated in the boot.




8. Secure the subframe uprights with the bolts and washers. Torque to 500 ft-lbs.

**IMPORTANT:** When mounting for the first time, the front hook bolts will have to be tightened after positioning the hook directly over the mounting boss (most rearward position).



9. Raise the loader and lock the support stand tubes into the up position.

**NOTE:** When mounting for the first time, raise the loader slowly and check to make sure that the hoses do not bind or become pinched in all positions. Work the loader and bucket up and down to work out all the air in the hydraulics. Check and refill the tractor's hydraulic system.



## Removing the Loader from Your Tractor




**WARNING!** When removing the loader, it must be fitted with a bucket or other suitable attachment to give the frame stability after removal. If this is not done, the frame will not remain standing.




**IMPORTANT!** Always remove the loader on firm, level ground (away from children's play areas and high traffic areas). This makes attaching and removing much faster and easier. It also makes the free standing loader more stable.


1. Raise the loader, lower support stand tubes and lock into position



2. Lower the loader until the stand tubes are firmly on the ground and then dump the bucket so that it is also firmly on the ground. There should be slight downward pressure.




3. Loosen the bolts from the rear of the subframe boots and swing bolt up into lock position.



## Removing the Loader from Your Tractor (Continued)


4. Roll back the bucket slightly and simultaneously extend or retract the lift cylinders to free hooks from spools. Then slowly back up the tractor.




5. Once the subframe is clear of the boot and the hook is clear of the mounting boss, roll back the bucket all the way. This raises the rear uprights of the loader.



**NOTE:** On some mountings, the lift cylinders must be extended more while the tractor is backing up, so that the subframes clear the front axle.




6. Continue backing up until the loader is clear.



**CAUTION!** Be sure the hoses **DO NOT** get pinched or catch on any frame members while backing up.

7. After the loader is clear, retract the lift cylinders to protect the shafts and disconnect the hydraulic lines at quick couplers.





# Trouble Shooting

PROBLEM	POSSIBLE CAUSE	REMEDY
Loader slow and/or will not dump.	Quick couplers leaking.	Check connections and compatibility or replace.
	Hydraulic oil too heavy.	Change or replace filter.
	Oil filter plugged.	Clean or replace filter.
	Hydraulic pump worn.	Repair or replace pump.
	Oil line restricted or leaking.	Check all hoses and tubes for leaks, damage or restrictions. Replace damaged or restricted hoses or tube lines.
	Control valve does not shift properly.	Inspect, clean, repair or replace valve.
	Air in hydraulic system.	Cycle lift cylinders and bucket cylinders several times to free system of air.
	Cylinder leaks internally.	Replace seals.
	Faulty valve.	Repair or replace valve.
Loader chatters or vibrates when raising and lowering.	Air leak in pump inlet line.	Check, tighten or replace inlet line.
	Air in hydraulic system.	Cycle lift cylinders and bucket cylinders.
	Oil level too low.	Add oil as required.
Excessive movement at pivots	Worn bushings and/or pins.	Replace bushings and/or pins.
Pump noisy	Inlet line restricted or leaking.	Check for air leaks, restrictions or collapsed hose. Tighten or replace hose. Clean filter if necessary.
	Oil level too low.	Add oil as required.
	Pump worn or damaged.	Repair or replace pump.
Oil leaks.	Damaged fittings or hoses.	Replace damaged parts.
	Loose connections.	Tighten fittings.
	Worn or damaged O-ring wiper seal in cylinder rod end.	Install a seal repair kit.
	Worn or damaged O-rings in valve.	Install an O-ring repair kit.
Insufficient lift capacity	Improper hydraulic pump operation.	Repair or replace pump.
	Load is greater than boom lift capacity.	Check loader specifications.
	Internal boom cylinder leakage.	Replace any worn parts and install a seal repair kit.
	Improper hydraulic valve operation.	Repair or replace valve.
Slow leakdown.	Worn control valve.	Have authorized dealer replace seals.
	Worn cylinder piston seals.	Have authorized dealer replace seals.
Excessive wear on bottom oil bucket and wear pads.	Float position not used while operating loader.	Use float position provided on valve.
Hydraulic cylinders inoperative.	Hose from control valve improperly connected.	Refer to plumbing diagrams.
Pump operating continually on closed center tractor hydraulic system.	Tractor control valve relief stuck open.	See your tractor manual for proper adjustment or Loader dealer for loader valve. (3000 PSI is maximum pressure relief setting recommended.)
	Hydraulic control valve set too low.	Adjust valve in accordance with manual.
Loader lift and bucket tilt controls do not work according to decal.	Hoses improperly connected.	Refer to plumbing diagrams and correct hose connections.
	Valve noisy and/or hot	Replace relief valve with closed center plug and plug the power beyond adapter on valve.
Tractor loads/pump squeals	Closed center control valve on open center tractor.	Install open center plug on optional valve. Replace closed center plug with relief and install short plug in place of power beyond adapter.

## **General Notes and Instructions to the Operator Regarding ALLIED TSL Loader Operations**

1. The *true self levelling system* (TSL) utilizes mechanical linkages to maintain bucket level while raising and lowering. The pivot plate weldment, levelling tubes and linkages have been developed to ensure that the bucket remains at the same position throughout its range of motion. This feature is standard with 2.50" and 3.00" diameter bucket cylinders.
2. The TSL system incorporates a relief and anticavitation manifold to provide extra dump at ground and rollback at full lift height. This feature is available on 3.00" bucket cylinders only. **If the loader is raised with the bucket fully dumped**, oil from the bucket piston side will be bypassed at high pressure to the bucket shaft side and the lift shaft side as the quick attach contacts the dump stop. **If the loader is lowered with the bucket fully rolled back**, oil from the bucket shaft side will be bypassed at high pressure to the bucket piston side and makeup will be provided by the lift piston side as the quick attach contact the rollback stop. Note that these two conditions are likely to occur intermittently and although the pump will be forced to supply oil at a higher pressure, no damage to the loader components will occur. It is, however, recommended to avoid the above situations and keep the bucket somewhat level while raising or lowering the loader for smoother operation.
3. The extra bucket stroke length allows for the bucket to be dumped to approximately 90 degrees at ground. This allows for bucket assist when traction is minimal. If the loader is raised from this position, the bucket will retract as the quick attach contacts the dump stop and the circuit goes through relief as described in note 2.
4. Extra bucket retraction allows for the bucket to be rolled back as the loader raises. The TSL feature maintains the bucket level, but as required the bucket can be manually rolled back approximately 20 degrees to allow for increased bucket capacity. If the loader is lowered from this position, the bucket will extend as the quick attach contacts the rollback stop and the circuit goes through relief as described in note 2.
5. The relief valve is factory set at 3250 PSI cracking pressure and is capable of bypassing 10-15 GPM. If loader lock-up should occur due to a low tractor relief setting, higher inlet flows or return line restrictions, the relief valve may be backed off slightly until the lock-up condition is overcome (counterclockwise turn of set-screw). Contact the factory for further instructions.

# 995 TSL, S995 TSL Main Frame Assembly






## 995 TSL, S995 TSL Main Frame Parts Table


Item	Part No.	Description	995 TSL Quantity	S995 TSL Quantity
1	24701	995 TSL Mainframe	1	-
1	24722	S995 TSL Mainframe	-	1
2	24705	Quick Attach Left	1	1
3	24706	Quick Attach Right	1	1
4	113102	Cross Tube	1	1
5	108827	Pin Weldment	2	2
6	114304	Stand Tube	2	2
7	114303	Stand foot	2	2
8	113690	Link Spacer	2	2
9	110907	Stand Pin 0.625 diameter	2	2
10	12779	Hair Pin Clip	4	4
11	114173	Levelling Rod	1	1
12	113587	Pin 1.25 X 8.75 LG	2	2
13	113660	Pin 1.25 DIA X 6.00 LG	2	2
14	113696	Pin 1.25 DIA X 8.13 LG	6	6
15	113924	Levelling Tube	2	2
16	24242	Cross Tube Cover	1	1
17	24707	Cylinder Bucket	2	2
18	24830	Cylinder Lift	2	2
19	114250	Pin 1.50 dia. X 8.75 LG	2	2
20	81581	Hex Bolt 0.375 DIA X 2.5 LG	32	32
21	81669	Hex Bolt 0.625 DIA X 3.5	4	4
22	81592	Hex Nut 0.375 DIA	4	4
23	81344	Locknut 0.375 DIA	41	41
24	81967	Locknut 0.625 DIA	18	18
25	113691	Bushing 1.25 I.D. X 1.63 O.D x 0.75" lg	8	8
26	81570	Flat Washer 0.375 DIA	4	4
27	113633	Bushing 1.25 I.D. X 1.63 O.D. x 1.88" lg	16	16
28	113579	Bushing 1.50 I.D. x 1.88 O.D. x 1.88" lg	4	4
29	114100	Pin 1.25 DIA X 8.38 lg	4	4
30	114175	Pin 1.25 DIA X 9.13 lg	4	4
31	114095	Link Weldment Left	2	2
32	114096	Link Weldment Right	2	2
33	81966	Locknut 0.50 DIA	2	2
34	84583	Grease Fitting 1/8 NPT Straight	2	2
35	FNH114039	Bolt Plate	1	1
36	FNH114040	Rod Guide	1	1
37	114097	Link Assembly 11.25	4	4
38	24704	Pivot Plate Left	1	1
39	24702	Pivot Plate Right	1	1
40	813228	1/2" Wing nut (pl)	2	2
41	81637	1/2" Lock washer (PI)	2	2
42	813356	Decal - Buhler Allied X 1.75	2	2
43	114132	Decal - TSL X 1.75	2	2
44	813358	Decal - True Self Leveling	2	2
45	113488	Decal - Quick Attach Instruction	2	2
46	52281-000	Bright Orange Scotchcal #72368	10ft	10ft
47	114251	Pin 1.25 DIA X 8.75 lg	2	2

# 995 TSL, S995 TSL

## Hydraulic Plumbing Diagram



### Manifold Kit X2547





## 995 TSL, S995 TSL Plumbing Parts Table

Item	Part No.	Description	Quantity
1	24830	3.0 DIA x 32.50 Cylinder Assembly Lift	2
2	24707	3.0 DIA x 24.75 Cylinder Assembly Bucket	2
3	812069	Tee 3/4-16MJIC X 3/4-16 MJIC	4
4	886704	Adaptor Str 3/4 MJIC x 3/4 MJIC	2
5	811414	Elbow 90° 3/4-16 MORB to 3/4 MJIC	2
6	812128	Elbow 90° 3/4 MJIC x 3/4 MJIC	4
7	11362	Pipe Clip	9
8	112937	Tubing Ext. Lift Cyl 31.0"	2
9	114107	Tubing Lift Cyl. (Bottom, Raise)	1
10	114105	Tubing Lift Cyl. Right (Top, Drop)	1
11	114109	Tubing Bucket Cyl. (Bottom, Dump)	1
12	114108	Tubing Bucket Cyl. (Top, Rollback)	1
13	114916	Tubing Lift Cyl. Left (Bottom, Raise)	1
14	114106	Tubing Cross Tube	2
15	114605	Hose 3/8 X 24 3/4-16 MORB X 3/4-16 SWFJIC	2
16	812697	Hose 3/8 X 24 3/4-16 SWFJIC X 3/4-16 SWFJIC	2
17	811434	Hose 3/8 X 30 3/4-16 MORB X 3/4-16 SWFJIC	2
18	114228	Tubing Lift Cylinder Left (Top, Drop)	1
19	811574	Hose 3/8 X 40 3/4-16 MORB X 3/4-16 SWFJIC	2

### Parts List for X2547 TSL Manifold Kit\*


Item	Part No.	Description	Quantity
1	24750	TSL Manifold	1
2	114605	Hose 3/8 x 24 3/4-16 MORB x 3/4-16 SWFJIC	2
3	811434	Hose 3/8 x 30 3/4-16 MORB x 3/4-16 SWFJIC	2
4	812069	Tee 3/4-16MJIC X 3/4-16 MJIC	2
5	812786	Tee 3/4 MJIC x RUN x 3/4 SWFJIC	2
6	812052	Bolt Hex 0.250nc x 3.00 gr5 pl	2
7	81922	Nut Lock (Nylon) 0.25nc grbpl	2

\* Required only if cartridge valve kit X2264 not purchased.

## 995 TSL , 995S TSL Hydraulic Cylinder Assembly

Description	Bucket Cylinder	Lift Cylinder	Lift Cylinder
Diameter	3.00"	3.00	3.50"
Length of Stroke	24.75"	32.50"	32.50"
Retracted Length	61.75"	52.50"	52.50"
Extended Length	86.50"	85.00"	85.00"
Cylinder Assembly No.	24707	24830	24607
Seal Kit No.	X1424	X1424	X1425
Shaft Diameter	1.75"	1.75"	2.00"

Item	Description	Part No.	Part No.	Part No.
1	Head Plate	24606	24606	24430
2	Shaft	114135	114930	113700
3	Cylinder Tube	24699	24786	24785
4	Piston Half (wide)	112862	112862	112940
5	Piston Half (narrow)	112863	112863	112941
6	Self-Locking Nut	810457	810457	810457
7	Shaft Bushing	113766	113766	113766



**NOTES:**


1. Bucket cylinder shown.
2. All cylinder seals are contained in corresponding seal kit.



**CAUTION: Maximum pressure 2750 psi**


# WARNING!

LOOK OUT FOR CHILDREN.  
TEACH YOUR CHILDREN SAFETY.  
(INFORM THEM OF DANGERS AROUND MACHINES)




MANUAL MUST BE READ AND UNDERSTOOD BY OPERATOR.

## TRANSPORT




EMBLEMS MUST BE VISIBLE

ALWAYS MOVE EQUIPMENT IN LOW OR DOWN POSITION ESPECIALLY AROUND POWER LINES.



NEVER LEAVE EQUIPMENT IN RAISED POSITION.

POWER LINES CAN KILL



## SERVICE



SERVICE EQUIPMENT ONLY WHEN STOPPED AND WITH LIFT LOCKS IN PLACE AS SHOWN.

KEEP ALL GUARDS AND SHIELDS IN PLACE.




REPLACE DAMAGED OR WORN PARTS. FRAYED CABLES AND HOSES ARE DANGEROUS.

DO NOT CHANGE FACTORY SETTINGS.

KEEP DECALS CLEAN AND LEGIBLE.  
(REPLACEMENTS NORMALLY AVAILABLE)



LIFT LOCK



**FACTORY LOCATIONS**

Allied Factory  
 1201 Regent Ave. W.  
 Box 1003  
 Winnipeg, MB  
 R2C 3B2  
 Ph.: (204) 661-8711  
 Fax: (204) 654-2503

Farm King Factory  
 301 Mountain Street S.  
 Morden, MB  
 R6M 1X7  
 Ph.: (204) 822-4467  
 Fax: (204) 822-6348

Inland Factory  
 675 Washington Ave.  
 Winnipeg, MB  
 R2K 1M4  
 Ph.: (204) 667-7854  
 Fax: (204) 791-3596

**CANADIAN WAREHOUSES**

B.C., Abbotsford  
 (604) 864-2665

AB, Edmonton  
 (403) 962-6991

SK, Regina  
 (306) 781-2300

ON, Woodstock  
 (519) 539-0435

ON, Jasper  
 (613) 283-1758

PQ, Dorion  
 (405) 455-4840

**buhler manufacturing**

*"a partnership"*

1201 Regent Ave. W.  
 Box 1003  
 Winnipeg, MB  
 R2C 3B2  
 Ph.: (204) 661-8711  
 Fax: (204) 654-2503  
[www.buhler.com](http://www.buhler.com)

**U.S. WAREHOUSES**

AR, West Memphis  
 (501) 732-3132

GA, Stone Mountain  
 (770) 908-9439

IA, Atlantic  
 (712) 243-5520

IA, Lakeview  
 (712) 657-8585

ID, Meridian  
 (208) 887-6006

IL, Hooppole  
 (815) 948-2591

IL, LeRoy  
 (309) 787-4659

IN, Clarksville  
 (812) 284-3376

IN, Crawfordsville  
 (317) 362-4495

KS, Wichita  
 (316) 265-9577

MN, Lakeville  
 (952) 469-5267

MT, Billings  
 (406) 248-7771

NE, Gothenburg  
 (308) 537-7175

NC, Goldsboro  
 (919) 735-6281

NC, Statesville  
 (704) 873-0531

ND, Bismarck  
 (701) 223-1886

ND, Fargo  
 (701) 282-7003

NY, Oneida  
 (315) 363-3390

NY, Syracuse  
 (315) 463-5276

OH, Youngstown  
 (216) 793-0862

OR, Portland  
 (503) 234-0378

SD, Huron  
 (605) 352-8616

TX, Houston  
 (713) 928-2632

UT, Salt Lake City  
 (801) 972-4321

WI, Portage  
 (608) 742-1370

**OFFSHORE WAREHOUSES**

Burando Hill  
 Katanning  
 W. Australia

Chihuahua, Mexico  
 011-52-158-90306

John Kerr Equipment Ltd.  
 Wilcoxholm Farm  
 Linlithgow, W. Lothian  
 Scotland

Naestved, Denmark  
 011-45-557-29511

Skovde, Sweden  
 011-46-500-452651