


bühler

farm king



50", 60", 72" & 82"
65 Series Rotary Tiller

Operator's and Parts Manual
FK302

2009

TABLE OF CONTENTS

DESCRIPTION	PAGE
Warranty	1
Introduction	2
SAFETY	3
Safety	3
General Safety	4
Start Up Safety	4
Operation Safety	4
Transport Safety	4
Service & Maintenance Safety	5
Storage Safety	5
Safety Signs	5
Safety Sign Installation	5
 ASSEMBLY	 7
Assembly Instructions	7
 START UP	 8
Machine Break-In	8
Pre-Operation Checklist	8
 OPERATION	 9
Machine Components	9
Equipment Matching	10
Driveline Dimension	11
Attaching/Unhooking	13
Field Operation	15
Transporting	18
Storage	19
Theory of Operation	20
 MAINTENANCE	 21
Service	21
Fluids and Lubricants	21
Greasing	21
Servicing Intervals	22
A-Frame Adjustment	24
Tine Replacement	24
Slip Clutch	25
Clutch Maintenance	26
Main Shaft Replacement	27
Troubleshooting	28
Bolt Torque	29

PARTS LISTS

Tiller Drawings and Parts List	30
PTO (Slip Clutch) Drawing	36
PTO (Slip Clutch) Parts List (50", 60", 72")	37
PTO (Slip Clutch) Parts List (82").....	38
Gearbox Drawing & Parts List (50", 60" & 72")...	39
Gearbox Drawing & Parts List (82")	40

SHIPPING KIT AND BUNDLE NUMBERS	41
--	-----------

WARRANTY POLICY

Buhler Manufacturing products are warranted for a period of twelve (12) months (90 days for commercial application) from original date of purchase, by original purchaser, to be free from defects in material and workmanship under correct, normal agricultural use and proper applications.

Buhler Manufacturing's obligations under this warranty shall be limited to the repair or exchange, at Buhler Manufacturing's option, of any Buhler Manufacturing product or part which proves to be defective as provided. Buhler Manufacturing reserves the right to either inspect the product at the buyer's location or have it returned to the factory for inspection.

The above warranty does not extend to goods damaged or subject to accident, abuse or misuse after shipment from Buhler Manufacturing's factory, nor to goods altered or repaired by anyone other than an authorized Buhler Manufacturing representative.

Buhler Manufacturing makes no Express Warranties other than those, which are specifically described. Any description of goods, including any references and specifications in catalogues, circulars and other written material published, is for the sole purpose of identifying goods and shall conform to such descriptions. Any sample or model is for illustrative purposes only and does not create an Express Warranty that the goods conform to sample or model shown.

The purchaser is solely responsible for determining suitability of goods sold. This warranty is expressly in lieu of all other warranties expressed or implied. Buhler Manufacturing will in no event be liable for any incidental or consequential damages whatsoever. Nor for any sum in excess of the price received for the goods for which liability is claimed.

WARRANTY CLAIMS:

Warranty requests must be prepared on Buhler Manufacturing Warranty Claim Forms with all requested information properly completed. Warranty Claims must be submitted within a thirty (30) day period from date of failure repair.

WARRANTY LABOR:

Any labor subject to warranty **must** be authorized by Buhler Manufacturing. The labor rate for replacing defective parts, where applicable, will be credited at 100% of the dealer's posted shop rate. Defective parts will receive an extra 10% discount to assist with freight or other incidental costs.

GOVERNMENT LEGISLATION:

Warranty terms and conditions are subject to Provincial or State legislation.

IMPORTANT FACTS:

Buckets and Bucket Tines Carry No Warranty
Bent Spears Carry No Warranty
Snowblower Fan Shafts Carry No Warranty
Mower Blades Carry No Warranty
Portable Auger Parts Have Two (2) Year Warranty
Loader Parts Have Two (2) Year Warranty

IMPORTANT NOTE: This warranty does not apply to rentals

INTRODUCTION

Buhler Farm King has a collection of rotary tiller models to suit your garden and landscaping needs. The 65 Series Tiller attaches to the 3-point hitch as well as Cat. 1 & 2 Quick Hitch, and is designed to fit a variety of tractors, from 30 hp to 65 hp. Tilling widths range from 46" to 77" in the 65 Series.

The tilling shaft is equipped with five to eight flanges, depending on the model. Flanges on all series are available with four tines, and six tines per flange are standard on the 65 series. This provides an optimum balance between performance and durability, even in heavy soils and when breaking untilled soil.

Standard on all Buhler Farm King Rotary Tillers, the skid shoes are adjustable so it is easy to set the perfect tilling depth. The automatic chain tightener is standard on all models. This ensures the chain remains tight even under the toughest tilling conditions. Housed within a sealed oil bath, the chain tightener is designed to be reliable and maintenance-free. Getting close to fences, hedges or covering a tire track is easy with the side shift feature. The entire unit can be pushed to one side, while the PTO shaft remains in line with the tractor to minimize stress on the universal joint. The side shift feature is available on all Buhler Farm King Rotary Tillers except the C6582.

Keep this manual handy for frequent reference. All new operators or owners must review the manual before using the equipment and at least annually thereafter. Contact your Buhler Dealer if you need assistance, information, or additional copies of the manual. Visit our website at www.buhler.com for a complete list of dealers in your area.

The directions left, right, front and rear, as mentioned throughout this manual, are as seen facing in the direction of travel of the implement.

SAFETY

Remember, YOU are the key to safety. Good safety practices not only protect you, but also the people around you. Make these practices a working part of your safety program. Be certain that everyone operating this equipment is familiar with the recommended operating and maintenance procedures and follows all the safety precautions. Most accidents can be prevented. Do not risk injury or death by ignoring good safety practices.

The alert symbol is used throughout this manual. It indicates attention is required and identifies hazards. Follow the recommended precautions.



The safety alert symbol means...

ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!

CAUTION

The caution symbol indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

WARNING

The Warning Symbol indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury, and includes hazards that are exposed when guards are removed. It may also be used to alert against unsafe practices.

DANGER

The Danger Symbol indicates an imminently hazardous situation that, if not avoided will result in death or serious injury. This signal word is to be limited to the most extreme situations, typically for machine components that, for functional purposes, cannot be guarded.

GENERAL SAFETY

Have a first-aid kit available for use and know how to use it.

Have a fire extinguisher available for use and know how to use it.

Wear appropriate protective gear. This list includes but is not limited to:

- a hard hat
- Protective shoes with slip resistant soles
- Protective glasses or goggles
- Heavy gloves
- Wet weather gear
- Hearing protection
- Respirator or filter mask

Read and understand the Operator's Manual and all safety signs before operating, servicing, adjusting, repairing, or unplugging the equipment.

Do not attempt any unauthorized modifications to your Buhler product as this could affect function or safety, and could affect the life of the equipment.

Never start or operate the tiller except from the operator's station on the power unit.

Inspect and clean the working area before operating.

Keep hands, feet, clothing, and hair away from moving parts.

Ensure bystanders are clear of the area before operating.

START-UP SAFETY

Do not let inexperienced operators or children run this equipment.

Place all tractor and machine controls in neutral before starting.

Operate only with ROPS and seatbelt equipped tractors.

Do not operate inside a building unless there is adequate ventilation.

Ensure all shields are in place and in good condition before operating.

Stay clear of PTO shaft and machine when engaging PTO.

OPERATION SAFETY

Do not permit riders.

Do not wear loose fitting clothing during operation.

Never operate over 540 PTO rpm speed.

Never operate the equipment in the raised position.

TRANSPORT SAFETY

Review Transport Safety instructions in tractor manual before moving.

Check with local authorities regarding transport on public roads. Obey all applicable laws and regulations. Make sure the SMV (Slow Moving Vehicles) emblem and all the lights and reflectors that are required by the local highway and transport authorities are in place, are clean, and can be seen clearly by all overtaking and oncoming traffic.

Never have the equipment in operation during transport.

Always travel at a safe speed.

SERVICE AND MAINTENANCE SAFETY

Stop engine, set brake, remove ignition key, and wait for all moving parts to stop before servicing, adjusting, repairing, or unplugging.

Support the equipment with blocks or safety stands before working beneath it.

Follow good shop practices including

- keep service area clean and dry
- be sure electrical outlets and tools are properly grounded
- use adequate light for the job

Use only tools, jacks, and hoists of sufficient capacity for the job.

Replace and secure all shields removed during servicing before operating.

Use heavy leather gloves to handle sharp objects.

STORAGE SAFETY

Store the unit in an area away from human activity.

Do not permit children to play on or around the stored machine.

Support frame on stands and blocks to provide a secure base.

SAFETY SIGNS


The following illustration shows the approximate location and detail of safety signs.

Keep all safety signs clean and legible and replace any that are damaged or missing.

When original parts are replaced, any safety signs affixed to those parts should be replaced as well. Replacement safety signs are available from your local dealer.

INSTALLATION OF SAFETY SIGNS


To install safety signs, ensure the installation area is clean and dry. Decide on the exact position before you remove the backing paper. Remove the smallest portion of the split backing paper and align over the specified area. Carefully, press in place. Slowly peel back the remaining paper and smooth the remaining portion in place. Small air pockets can be pierced with a pin and smoothed out.



TL-37

SAFETY SIGN LOCATIONS - cont'd.

Safety sign "A"



Safety sign "B"



Safety sign "C"



Replace safety signs immediately should they become damaged, torn or illegible. Obtain replacements from your authorized dealer using the part numbers shown.

ASSEMBLY

The machine is shipped with the PTO shaft not installed.

To install the PTO driveline on the machine, follow this procedure:

1. Clear the area of bystanders, especially small children.
2. Clean the splines on the yoke and the input shaft.
3. Align the splines on the yoke and the shaft.
4. Attach the driveline to the tiller by removing the tapered pin and sliding the yoke onto the gearbox shaft. Line up the pin with the groove in the gearbox shaft and fasten with the tapered pin. The plastic gearbox PTO guard has a removable door on top to access the pin. The A-frame brace can be removed to improve accessibility. Replace the brace after tightening the nut on the tapered pin.
5. Be sure the yoke is locked in position. Pull on the yoke to be sure the pin clicks into position.
6. Be sure that the PTO shaft is the appropriate length for the tractor/Tiller combination. Refer to Driveline Dimension Section for details.

START-UP

MACHINE BREAK-IN

Although there are no operational restrictions on the Tiller when used for the first time, it is recommended that the following mechanical items be checked:

- A. After operating for 1/2 hour or after completing 1/2 acre:
1. Check all nuts, bolts and other fasteners. Tighten to their specified torque level.
 2. Check that the blades are in good condition and bolted securely to the rotor.
 3. Check the oil level in the gearbox. Add as required.
 4. Check that the PTO driveline shield turns freely.
 5. Lubricate all grease points.
- B. After operating for 5 hours and 10 hours:
1. Repeat items 1 through 5 of Section A.
 2. Then go to the regular service schedule as defined in Section 5.

PRE-OPERATION CHECKLIST

Efficient and safe operation of the Rotary Tiller requires that each operator reads and understands the operating procedures and all related safety precautions outlined in this section. A pre-operation checklist is provided for the operator. It is important for both personal safety and maintaining the good mechanical condition of the Tiller that this checklist is followed.

Before operating the machine and each time thereafter, the following areas should be checked off:

- Lubricate the machine per the schedule outlined in the Service and Maintenance Section.
- Use only a tractor of adequate power and weight to pull the machine.
- Check that the machine is properly attached to the tractor. Be sure retainers are used on the mounting pins.
- Check the oil level in the gearbox. Add as required.
- Check that the PTO driveline shield turns freely and that the driveline can telescope easily. Clean and lubricate if required.
- Check the blades. Be sure they are not damaged or broken and are bolted securely to the rotor. Repair or replace as required.
- Remove any entangled material on rotating parts.
- Install and secure all guards, doors and covers before starting.
- The four socket set screws on the inside of the PTO clutch assembly must be turned out as far as they go to engage the clutch.

OPERATION

TO THE NEW OPERATOR OR OWNER

The Buhler Farm King 65 Series Rotary Tiller is a machine that combines the primary and secondary tillage operation into one machine. It breaks up the soil and prepares the seed bed in one pass. Rotational power to the rotor is provided by the tractor PTO. Be familiar with the machine before starting.


It is the responsibility of the owner or operator to read this manual and to train all other operators before they start working with the machine. Follow all safety instructions exactly. Safety is everyone's business. By following recommended procedures, a safe working environment is provided for the operator, bystanders and the area around the work site. Untrained operators are not qualified to operate the machine.

Many features incorporated into this machine are the result of suggestions made by customers like you. Read this manual carefully to learn how to operate the machine safely and how to set it to provide maximum field efficiency. By following the operating instructions in conjunction with a good maintenance program, your Tiller will provide many years of trouble-free service.

MACHINE COMPONENTS

The Buhler Farm King 65 Series Rotary Tiller consists of a rotating drum that is equipped with bent blades for breaking up and leveling soil. The blades are turned through the soil while the machine moves over the working area. A Drag Shield is used to maintain a level seedbed. Rotational power to the drum is provided by the PTO on the tractor. The power is transmitted through the gearbox in the center of the machine to the chain drive down the side. The A-frame can be moved to offset the machine.

- A Point A-frame
- B PTO Driveline
- C Gear Box
- D Chain Drive
- E Rotor
- F Blades
- G Skid Plates



TL-38

EQUIPMENT MATCHING

To ensure the safe and reliable operation of the Tiller, it is necessary to use a tractor with the correct specifications. Use the following list as a guide in selecting a tractor to use on the machine.

1. **Horsepower:** Use Table 1 as a guide in selecting the tractor horsepower appropriate for your width of machine. Use only small Agricultural tractors on this machine.

Table 1 Horsepower vs. Width

Model	Width	Horsepower
50H	4.2 feet (1.3m)	40
60H	5 feet (1.5m)	45
72H	6 feet (1.8m)	55
82H	7 feet (2.1m)	65



ALERT: Do not exceed the recommended horsepower levels. The use of excess horsepower will void the warranty.

2. **Tractor Weight:**
By following the recommendations for the tractor power, the tractor will have sufficient weight to provide stability for the unit during field operation or when transporting. It is also recommended that each tractor be equipped with a full complement of suitcase weights on the front of the tractor. This will provide the required weight on the front for turning and extra traction if equipped with front wheel assist.
3. **3 Point Hitch:**
The Tiller is equipped with a Category 1, 3-point hitch. Be sure the tractor 3-point hitch is in the Category 1 configuration. Install the lift arm blocks or shorten the stop chains to place the arms into the non-sway configuration. Refer to the tractor manual for details.
4. **Load Sensing Hydraulics:**
Many newer tractors are equipped with “Load Sensing” hydraulics. It is the responsibility of the operator to set the tractor hydraulic system to provide “float” on the 3-point hitch. Refer to Tractor Manual for details. The float feature will allow the machine to follow the ground contours during operation.
5. **PTO Shaft:**
The tractor must have a 1 3/8” 6 spline 540 PTO rpm shaft to fit the driveline shaft supplied with the machine. Do not use shaft adapters or operate at any other speed. It is not recommended that a tractor with variable speed PTO’s be used on the Tiller. Operating at speeds faster than 540 PTO rpm will overload the drivetrain and lead to early failures.


Attach the safety chains supplied with the PTO shaft, allowing sufficient slack for the driveline during turns and operation. Check booklet attached to the PTO for instructions.

DRIVELINE DIMENSION

A PTO driveline is supplied with the machine. To accommodate the variety of 3 point hitch geometry available today, the driveline can be too long for some machines and must be cut. It is very important that the driveline be free to telescope but not bottom out when going through its working range. If the driveline bottoms out, the bearings on both the machine and tractor PTO shaft will be overloaded and fail in a short time.


If cutting the drive is necessary, follow this procedure:

1. Clear the area of bystanders, especially small children.
2. Attach the Tiller to the tractor but do not attach the driveline.
3. Raise the implement until the input gearbox shaft is at the closest point to the tractor output shaft.
4. In this position, measure the dimension between the locking groove on the tractor output shaft and the groove on the Tiller input shaft.



TL-45

5. Now measure the pin to pin dimension on the compressed driveline.



TL-39


6. If the driveline pin to pin dimension (B) exceeds the groove to groove dimension, the driveline should be cut.

DRIVELINE DIMENSION – cont'd.

7. To determine how much to cut off the PTO shaft ends, calculate “X” using the following formulas and the dimensions “A” and “B” from the previous steps.

$$X = B - A + 1/2''.$$

Pull the driveline apart and cut off the dimension determined “X” from each end.



TL-11

8. Be sure to use a hacksaw to cut from each end of the separated shaft. Cut both the plastic tube and the metal cores.
9. Use a file to remove the burrs from the edges that were cut.
10. Assemble the two ends of the shaft.
11. Make sure that the shaft can telescope freely. If it does not, separate the two parts and inspect for burrs or cuttings on the shaft ends. Be sure it telescopes freely before installing.
12. Make sure the plastic covering shield is free to rotate on the shaft before installing on the machine.

ATTACHING/UNHOOKING

The Tiller should always be located on a level, dry area that is free of debris and other foreign objects. When attaching the machine to a tractor, follow this procedure:

1. Clear the area of bystanders, especially small children.
2. Be sure the tractor 3 point hitch is in the Category 1 configuration and the lift arms are in the non-sway configuration (See tractor manual).
3. Make sure there is enough room and clearance to safely back up to the Tiller.
4. Attach the PTO driveline to the Tiller if it was removed for storage (See Assembly).
5. While backing up, align the lift arm balls with the mounting pins on the Tiller.
 **ALERT:** It may be necessary to add weight to the 3 point hitch to lower the lift arms.
6. Stop tractor, set park brake, remove ignition key and wait for all moving parts to stop before dismounting.
7. If your tractor is not equipped with a Quick Hitch:
 - a. Align the left lower link arm with the mounting pin.
 - b. Slide the ball over the pin and install the Linch Pin.
 - c. Use the screw jack on the right lift arm to align the ball with the pin.
 - d. Slide the ball over the mounting pin and install the Linch Pin.
 - e. Level the frame using the screw jack.
 - f. Remove retainer and pin from the mast.
 - g. Align top link using the turnbuckle.
 - h. Insert pin and install Linch Pin
 - i. Level frame using the turnbuckle.
8. If your tractor is equipped with a Quick Hitch:
 - a. Set the height of the 3 point hitch so the Quick Hitch claws are lower than the mounting pins.
 - b. Be sure the 3 point hitch is set in the non-sway position (See tractor manual for details.)
 - c. Align the claws under the mounting pins while backing up.
 - d. When the claws are under the pins, slowly raise the 3 point hitch. Be sure each of the mounting pins seat in their respective claw.
 - e. Release the claw retainer locks to secure the mounting pins in the claws.

ATTACHING/UNHOOKING – cont'd.


9. Attach the PTO driveline:
 - a. Check that the driveline telescopes easily and that the shield rotates freely.
 **CAUTION:** Be sure that the driveline does not bottom out when going through its working angles.
 - b. Attach the driveline to the tractor by retracting the locking pin, slide the yoke over the shaft and push on the yoke until the lock pin clicks into position. Pull on the yoke to be sure it is locked in position.
 - c. Attach the anchor chain on the driveline shield to the frame.
10. Use the 3 point hitch to raise the machine.
11. Unpin the front frame stand. Raise and pin in its storage position.
12. Remove the blocks from under the Depth Gauge Shoes.
13. Reverse the above procedure when unhooking from the tractor.

FIELD OPERATION

Buhler Farm King 65 Series Rotary Tillers are designed with the inherent flexibility of operating well in almost any kind of soil and terrain conditions. However, the operator has the responsibility of being familiar with all operating and safety procedures and following them.

Each operator should review this section of the manual at the start of the season and as often as required to be familiar with the machine. When using, follow this procedure:

1. Review and follow the pre-operation Checklist. Review Safety Instructions.
 2. Attach the tractor to the machine.
 3. Before going to the field review Transporting Section.
 4. Pull into the field and position the machine in a level area.
 5. Lower into working position.
 6. Set the machine:
 - a. Level the frame:
Use the screw jack on the right lift arm to level the frame from side-to-side.
 - b. Depth: Use the Depth Gauge Shoes on each side to set the operating depth. Position the Depth Gauge Shoes in the top hole for shallow tilling and in the bottom hole for deep tilling.
- ⚠️ ALERT:** In soft soil conditions, the skid plates become less effective and sink into the ground. Use the turnbuckle on the top link to set the frame angle so the bottom of the Depth Gauge Shoes are level when operating.



TL-40

FIELD OPERATION - cont'd.

- c. Offset:
The Category Pin Brackets can be moved 3 to 4 inches along the Deck Assembly to either side of center if required. Center the machine for normal operation. Offset if the tire tracks are wider than the machine or when tilling around trees, bushes or other areas.
 **ALERT:** Sliding offset feature not available in the 82" model.
 - d. Drag Shield:
Adjust the chain in the Adjustment Bracket to set the height of the Drag Shield. Set the Drag Shield to just contact the tilled soil when operating.
7. Align the unit with the working area.
 8. Starting machine:
 - a. Run the engine at low idle.
 - b. Slowly engage the PTO control to start the machine.
 - c. Slowly bring the engine to the rated PTO rpm speed. Never exceed rated speed.
 - d. Lower the machine to the ground and proceed down the field.
 9. Stopping machine:
 - a. Slowly decrease engine speed to low idle.
 - b. Raise machine out of the ground.
 - c. Disengage PTO clutch slowly. **CAUTION:** Place all controls in neutral, lower machine, stop engine, set park brake. Remove ignition key and wait for all moving parts to stop before dismounting.
 10. Ground Speed:
Travel speed can vary between 2 and 5 mph (3 and 8 km/h) depending on the soil and terrain conditions. It is the responsibility of the operator to note the condition of the job being done and set the speed to obtain a quality tilling job and maintain control of the machine. The speed can be increased to optimize tilling. Decrease speed if you want the soil worked to a finer texture.

FIELD OPERATION - cont'd.

11. Operating hints:
 - a. Determine the moisture content of the soil before starting. Soil that is too wet will "ball-up" in the rotor blades making tilling impossible. Sandy soils normally can be worked better than heavy clay or loam soils. It is the responsibility of the operator to determine the soil type and moisture content before starting. It may be necessary to wait for the soil to dry out before starting to work.
 - b. Set the length of the Top Link to obtain the quality of the job desired without needlessly using power and fuel in churning the soil. Use the condition of the seedbed as your guide.
 - c. When tilling hard or compacted soils, it is recommended that two passes be used when working. Use the Depth Gauge Shoes on each side of the frame to adjust the tilling depth of the machine. The second pass should be made at an angle to the first to give a consistent job and minimize compaction.
 - d. Always remove heavy crop cover, all grass and weeds, before starting to prevent rotor plugging.
 - e. The rotation of the Tines propel the machine in the forward direction. Always use the tractor transmission to control the speed of forward travel.
 - f. Always disengage the PTO control and raise the machine out of the ground before depressing the master clutch on the tractor.
 - g. Use low gear on the tractor to start the job. Increase the speed of forward travel only as the quality of the job and power available will allow.
 - h. If the slip clutch slips, reduce the ground speed or raise the machine slightly out of the ground.

TRANSPORTING

When transporting the machine, review and follow these instructions:

1. Be sure all bystanders are clear of the machine.
2. Be sure that the machine is securely attached to the tractor and all retainer pins are installed.
3. Clean the SMV emblem, lights and reflectors and be sure they are working.
4. Be sure you are in compliance with all applicable lighting and marking regulations when transporting. Check with your local authorities.
5. Be sure your machine can clearly be seen by overtaking and oncoming traffic.
6. Keep to the right and yield the right-of-way to allow faster traffic to pass. Drive on the road shoulder if permitted by law.
7. Do not allow riders.
8. Always use hazard flashers on the tractor when transporting unless prohibited by law.
9. Use pilot vehicles front and rear when transporting during times of limited visibility.
10. Never transport the machine faster than 20 mph (32 km/h). The ratio of the tractor weight to the Tiller weight plays an important role in defining acceptable travel speed. Table 2 summarizes the recommended travel speed to weight ratio.

Table 2 Speed vs. weight Ratio


Road Speed	Weight of fully equipped or loaded implement(s) relative to weight of towing machine
Up to 32 km/h (20 mph)	1 to 1, or less
Up to 16 km/h (10 mph)	2 to 1, or less
Do not tow	More than 2 to 1

STORAGE

After the season's use, the machine should be thoroughly inspected and prepared for storage. Repair or replace any worn or damaged components to prevent any unnecessary down time at the start of next season. To insure a long, trouble free life, this procedure should be followed when preparing the unit for storage:

1. Clear the area of bystanders, especially small children.
2. Thoroughly wash the machine using a pressure washer to remove all dirt, mud, debris and residue.
3. Inspect the blades and rotors for damage or entangled material. Repair or replace damaged parts. Remove all entangled material.
4. Change the oil in the gear box.
5. Lubricate all grease fittings. Make sure that all grease cavities have been filled with grease to remove any water residue from the washing.
6. Touch up all paint nicks and scratches to prevent rusting.
7. Move to storage area.
8. Select an area that is dry, level and free of debris.
9. Place blocks under the Depth Gauge Shoes.
10. Unhook from tractor.
11. If the machine cannot be placed inside, cover with a waterproof tarpaulin and tie securely in place.
12. Store the machine in an area away from human activity.
13. Do not allow children to play on or around the stored machine.

THEORY OF OPERATION



TL-46

MAINTENANCE**SERVICE**

Follow Maintenance Safety Instructions as outlined in Maintenance Safety.

FLUIDS AND LUBRICANTS

1. Hydraulic Oil:
Use standard hydraulic oil for all operating conditions.
2. Gear Box Oil:
Use an SAE 85W90 gear oil for all operating conditions.

Gear Box Capacity: 1 U.S. quart (0.95 liter)
3. Chain Case Grease:
Use a multi purpose grease for all operating conditions.
If chain case is removed, refill with 800 grams of grease.
4. Storing Lubricants:
Your machine can operate at top efficiency only if clean lubricants are used. Use clean containers to handle all lubricants. Store them in an area protected from dust, moisture and other contaminants.

GREASING

Use a Maintenance Checklist to keep a record of all scheduled maintenance.


1. Use a hand-held grease gun for all greasing.
2. Wipe grease fitting with a clean cloth before greasing, to avoid injecting dirt and grit.
3. Replace and repair broken fittings immediately.
4. If fittings will not take grease, remove and clean thoroughly. Also clean lubricant passageway. Replace fitting if necessary.

SERVICING INTERVALS

The periods recommended below are based on normal operating conditions. Severe or unusual conditions may require more frequent lubrication or oil changes.

8 Hours or Daily; Telescoping Tubes and Quick Disconnect 20 Hours

1. Lubricate PTO driveline (7 locations).




TL-41



ALERT: When using the safety chains supplied with the PTO shaft, the shield bearings must be kept lubricated.

80 hours or once a season:

2. Lubricate rotor driven end Bearing (1 location)



TL-42


3. Lubricate rotor drive end bearing (1 location).
4. Lubricate chain drive bearing (1 location)

- use 3 squirts only
- push grease in gradually

SERVICING INTERVALS – cont'd.


40 Hours

1. Check gearbox oil level.
Add as required



TL-16

2. Add approximately 10 squirts
of grease in chain case.



TL-43

Annually

1. Change gear box oil. Refill with SAE 85W90 gear oil.
2. Wash machine.

MAINTENANCE

By following a careful service and maintenance program for your machine, you will enjoy many years of trouble-free operation.

A-FRAME ADJUSTMENT

When moving the hitch along the front frame to adjust the offset, follow this procedure:

1. Clear the area of bystanders, especially small children.
2. Raise the machine so it is slightly out of the ground.
3. Loosen the U-bolts through the Category Pin brackets.
4. Slide the hitch along the Deck until the machine is set at the desired offset.
5. Tighten the U-bolts to their specified torque.

TINE REPLACEMENT

When the Tines are damaged in any way, they will need to be replaced. When replacing, follow this procedure:

1. Clear the area of bystanders, especially small children.
2. Raise the machine until the Tines are slightly above the ground.
3. Stop engine, set park brake, remove ignition key and wait for all moving parts to stop before dismounting.
4. Place blocks under each Depth Gauge Shoe to support the machine.
5. Raise the Drag Shield and secure in the up position.
6. Wear leather or heavy canvas gloves when handling Tines.
7. Remove mounting bolts from Tines.



ALERT: An alternate method would be to disconnect the machine from the tractor and tip it forward on its nose.

8. Install a new replacement blade and tighten the mounting bolts to their specified torque.
9. Lower the rear gate.
10. Remove the blocks under the skid plates.

SLIP CLUTCH

During normal operation, the slip clutch can release and slip when encountering an obstruction or when overloaded. It is designed to slip when the load exceeds 3 times its nominal rating. When the clutch slips too frequently during normal operating conditions, it is necessary to replace the clutch linings. **NOTE:** The PTO shafts are shipped with the slip clutch disengaged. There are four socket set screws on the inside of the clutch assembly, which are turned out as far as they go to engage the clutch. Disengage clutch by turning set screws in fully.

To replace clutch linings, follow this procedure:

1. Disengage the clutch by turning the four set screws all the way in.
2. Remove the outside bolts from the clutch assembly and replace the clutch linings.
3. When re-tightening the bolts, stop when the clutch spacer starts to touch the clutch plates. You should be able to just move the spacer by hand when you have the correct bolt torque.
4. Engage clutch by turning out set screws after assembly is complete.

CLUTCH MAINTENANCE

1. Before first use or after storage of more than one month, the clutch should be checked.
2. Disengage clutch by turning in the four socket set screws.
3. Run the PTO at low idle to slip the clutch linings. This will help remove the dirt, corrosion, and surface gloss from the clutch plates and also ensure that the linings are loose.
4. Engage the clutch by turning out the socket set screws.
5. Normally the clutch will slip at a 20% higher torque after the “run in” than before.
6. Check the temperature of the clutch after running for 20 minutes and every 8 hours after that. If the clutch is hot to the touch or smokes, check that the outside bolts are correctly tightened as explained in slip clutch section. If clutch still slips, linings may have to be replaced.

REPAIR

MAIN SHAFT REPLACEMENT

The main shaft is designed with a replaceable Final Drive Assembly on the driven end. This feature keeps the cost of repairs down should replacement be required and makes main shaft replacement easier.

When replacing the Final Drive Assembly, follow this procedure;

1. Clear the area of bystanders, especially small children.
2. Unhook from the tractor.
3. Remove the driveline and store to the side.
4. Remove the chain cover, the chain and the sprocket.
5. Use 2 people or a hoist to tip the machine forward on its nose.
6. Lift the Drag Shield up and lay forward.
7. Remove the mounting bolts connecting the Main Shaft to the Final Drive Assembly.
8. Wear leather or heavy canvas gloves when handling the Main Shaft and Tines.
9. Remove the Final Drive Assembly from the machine.
10. Install the replacement part.
11. Install and tighten the connecting bolts to their specified torque.
12. Install the sprocket and chain.
13. Tip the machine into the upright position.
14. Refill the chain cover with approximately 800 grams of multi-purpose grease.
15. Use gasket compound and replace the chain cover.
16. Be sure all fasteners are tightened to their specified torque.

TROUBLE SHOOTING

The Buhler Farm King 65 Series Rotary Tiller moves curved Tines on a turning rotor through the ground to break it up and prepare a seed bed. It is a simple and reliable system that requires minimal maintenance.

In the following section, we have listed many of the problems, causes and solutions to the problems that you may encounter.




If you encounter a problem that is difficult to solve, even after having read through this trouble shooting section, please call your local Buhler Farm King distributor dealer. Before you call, please have this Operator's Manual and the serial number from your Tiller ready.

PROBLEM	CAUSE	SOLUTION
Rotor won't turn.	Slip clutch slipping. or replace friction plates.	Check that clutch is engaged or replace friction plates.
	PTO clutch slipping.	Set PTO clutch. See tractor manual.
	Broken drive chain.	Repair or replace chain.


Untilled ground behind machine.	3 point hitch not set.	Set 3 point hitch in float. See tractor manual.
	Traveling too fast.	Travel slower.
	Ground very hard.	Slow down. Make 2 passes.
	Machine not leveled.	Adjust screw jack on 3 point arm. Adjust Depth Gauge Shoes.

Seed bed lumpy.	Traveling too fast.	Slow down. Make 2 passes.

Uneven seed bed.	Machine not level.	Level machine.
	Drag Shield too high.	Adjust Drag Shield.


Bolt Torque						
						
Bolt Diameter	SAE2		SAE5		SAE8	
"A"	N.m	lb-ft	N.m	lb-ft	N.m	lb-ft
1/4"	8	6	12	9	17	12
5/16"	13	10	25	19	36	27
3/8"	27	20	45	33	63	45
7/16"	41	30	72	53	100	75
1/2"	61	45	110	80	155	115
9/16"	95	70	155	115	220	165
5/8"	128	95	215	160	305	220
3/4"	225	165	390	290	540	400
7/8"	230	170	570	420	880	650
1"	345	225	850	630	1320	970

50", 60" & 72" SERIES TILLERS



TL-32

50", 60" & 72" "65" SERIES TILLERS



TL-32a

PARTS LIST

WHEN ORDERING PARTS

Always give your dealer the Model, Color and Serial Number of your machine to assist him in ordering and obtaining the correct parts. Use the exploded view and tabular listing of the area of interest to exactly identify the required part.


50", 60", 72", & 82" 65 Series Tillers

Item	Part #	Description
1	906904	Chain Guard
2	967164	Pound-In Grease Fitting
3	912300171	100B16 Sprocket
4	959221	Bottom Sprocket Spacer 3 1/2"OD x 1.07"
5	81592	3/8" Hex Nut
6	903193	Cat. Pin Bracket Weldment - Right
7	906312	100H Roller Chain (38 Link w/ Connector)
8	912301557	1 5/8" Retainer Ring
9	912300170	100B11 Sprocket
10	912301556	1 3/4" Retainer Ring
11	982000500	Side Stand Weldment
12	912301660	Snapper Clip
13	982006422	1 5/8" Oil Seal Plate
14	967363	1 5/8" Four Bolt Flange Bearing
	967364	1 5/8" Bearing Only
15	967361	7/8" X 4" Clevis Pin
16	965911	7/16" Linch Pin
17	906297	Deck Weldment (50")
	906298	Deck Weldment (60")
	906299	Deck Weldment (72")
	906300	Deck Weldment (82")
18	959227	1 5/8" Hex Shaft (50")
	959228	1 5/8" Hex Shaft (60")
	959229	1 5/8" Hex Shaft (72" & 82")
19	84268	5/8" x 1 1/2" Hex Bolt (pl)
20	967372	5/8" U-Bolt
21	903171	Spacer 1.05" OD x 2 1/4"
22	982505211	Drive Shaft Shield (50")
	982605211	Drive Shaft Shield (60")
	982725211	Drive Shaft Shield (72")
23	982505311	Drive Shaft Shield (50")
	982605311	Drive Shaft Shield (60")
	982725311	Drive Shaft Shield (72")

24	982825212	Drive Shaft Shield (82")
25	F0354	PTO Shaft w/ Slip Clutch (50", 60", & 72")
	F0355	PTO Shaft w/ Slip Clutch (82" only)
26	967392	Gearbox PTO Guard (50", 60", & 72")
	912300160	Gearbox PTO Guard (82")
27	982005111	Drive Shaft Shield Mount
28	967558	S4073 Gearbox (50", 60", & 72")
	912300159	4083 F Gearbox (82" only)
29	903320	Drive Shaft Shield (50", 60", & 72")
30	982825221	Drive Shaft Shield (82")
31	968632	1 1/2" - Four Bolt Flange Bearing
	967295	1 1/2" Bearing only (Greaseable)
32	982000350	Left Depth Gauge Shoe Weldment
33	982000300	Right Depth Gauge Shoe Weldment
34	982006400	Right Shaft Cover Cone
35	982506200	Main Shaft - 6 Tine (50")
	982606200	Main Shaft - 6 Tine (60")
	982726200	Main Shaft - 6 Tine (72")
	967421	Main Shaft - 4 Tine (50")
	967422	Main Shaft - 4 Tine (60")
	967423	Main Shaft - 4 Tine (72")
	982826200	Main Shaft - 6 Tine (82")
	967424	Main Shaft - 4 Tine (82")
36	81593	3/8" Lock Washer
37	982000471	1/4" x 14 Link Chain
38	967357	Drag Shield Lift Bracket
39	903187	Cat. Pin Bracket Weldment - Left
40	909715	Drag Shield Hinge Rod (50")
	909712	Drag Shield Hinge Rod (60")
	909716	Drag Shield Hinge Rod (72")
	909717	Drag Shield Hinge Rod (82")
41	967379	Final Drive Assembly - 6 Tine
	967420	Final Drive Assembly - 4 Tine
42	909733	Drag Shield (50")
	909734	Drag Shield (60")
	909735	Drag Shield (72")
	909736	Drag Shield (82")
43	967485	Tine Right
44	967486	Tine Left
45	982006322	1 3/4" Oil Seal Plate (6 1/2" x 6 1/2")
46	959220	Top Sprocket Spacer 3"OD x 1.07"
47	967374	2" Four Bolt Flange Bearing
	967375	2" Bearing only
48	967393	Left Bearing Cover Cone
49	912303600	1 3/4" Oil Seal

50	912303601	1 5/8" Oil Seal
51	982000341	Depth Gauge Shoe Bracket
52	907306	LH Side Plate Assy
53	982005711	Tension Spring
54	967378	Chain Tensioner Weldment
55	81525	1/4" X 3/4" Hex Bolt
56	84498	1/4" Lock Nut
57	81627	1/2" X 3" Hex Bolt
58	81637	1/2" Lock Washer
59	81636	1/2" Hex Nut
60	967122	5/8" X 2 1/4" Hex Bolt Grade 8
61	812482	5/8" Lock Nut
62	84270	5/8" X 1 3/4" Hex Bolt
63	812763	1/2" X 1 1/2" Hex Bolt Grade 8 (NF)
64	812764	1/2" X 2" Hex Bolt Grade 8 (NF)
65	812765	1/2" Hex Nut Grade 8 (NF)
66	81659	5/8" X 1" Hex Bolt (NC)
67	81677	5/8" Lock Washer
68	84277	1/2" X 1 1/2" Hex Bolt
69	812364	1/2" Lock Nut
70	86171	3/8" X 1 1/4" Hex Bolt
71	84000	3/8" B.S. Flat Washer
72	84072	3/8" X 3/4" Hex Bolt
73	812363	3/8" Lock Nut
74	81549	5/16" X 3/4" Hex Bolt
75	81569	5/16" Lock Washer
76	9812767	1/2" Lock Washer Grade
77	965807	Cat. 1 Top Link Pin
78	81676	5/8" Hex Nut
79	84048	1/2" Flat Washer
80	81620	1/2" X 1 1/4" Hex Bolt
81	86170	3/8" X 1" Hex Bolt
82	903175	A-Frame Bottom Weldment
83	903179	A-Frame Top - Right Hand
84	903180	A-Frame Top - Left Hand
85	903181	A-Frame Brace Plate
86	811790	3/4" x 4 1/2" Hex Bolt
87	81700	3/4" Hex Nut
88	81701	3/4" Lock Washer
89	87553	1/2" X 1 3/4" Hex Bolt
90	81568	5/16" Hex Nut
91	909277	Manual Holder
92	9812432	1 1/4" Cotter Pin
93	812026	5/16" x 1" Hex Bolt

**65 SERIES TILLER PTO (SLIP CLUTCH)
(50", 60", 72" & 82")**



TL33

65 SERIES TILLER PTO PARTS LIST (SLIP CLUTCH) - 50", 60" & 72"

ITEM	PART NO.	DESCRIPTION
	F0354	Shaft Complete
	908262	Outer Half Shaft - Tractor
	936527	Inner Half Shaft - Implement
1	908259	Quick Disc Yoke - RS
2	966236	Repair Kit
3	936352	Outer Tube Yoke
4	936358	Flexible Pin
5	936368	Outer Cardan Tube
6	936369	Inner Cardan Tube
7	936359	Flexible Pin
8	936353	Inner Tube Yoke
9	936564	Torque Limit
10	966234	Outer Shield Collar
11	966232	Outer Shield Cone Set
12	936370	Outer Shield Safety Tube
13	936371	Inner Shield Safety Tube
14	936518	Inner Shield Cone Set
15	966235	Inner Shield Collar
16	907192	Ball & Collar Kit
17	910-075	Taper Pin Kits
18	936524	Spring Set
19	936520	Clutch Plate
20	936521	Clutch Lining
21	936523	Hub C/W Q.D.
22	936522	Thrust Plate
23	936519	Clutch Screw
24	936402	Complete Safety Chain
25	966223	Antifriction Sleeve
26	936526	Spacer
*27	936512	Set Screw

* Set Screw should be backed out all the way to engage clutch


65 SERIES TILLER PTO PARTS LIST (SLIP CLUTCH) - 82" ONLY

ITEM	PART NO.	DESCRIPTION
	F0355	Shaft Complete
	908263	Outer Half Shaft - Tractor
	936530	Inner Half Shaft - Implement
1	908260	End Yoke - RS
2	910-036	Repair Kit
3	910-039	Outer Tube Yoke
4	910-040	Flexible Pin
5	910-044	Outer Cardan Tube
6	910-045	Inner Cardan Tube
7	910-042	Flexible Pin
8	910-048	Inner Tube Yoke
9	936528	Torque limiter FT42
10	910-046	Outer Shield Collar
11	966232	Outer Shield Cone Set
12	910-052	Outer Shield Safety Tube
13	910-053	Inner Shield Safety Tube
14	936518	I. Cone Set
15	910-055	Inner Shield Collar
16	907192	Ball & Collar Kit
17	910-075	Taper Pin Kits
18	936524	Spring Set
19	936529	Clutch Plate
20	936521	Clutch Lining
21	936523	Hub C/W Q.D.
22	936522	Thrust Plate
23	936519	Clutch Screw
24	936402	Complete Safety Chain
25	966223	Antifriction Sleeve
26	936526	Spacer
*27	936512	Set Screw

* Set Screw should be backed out all the way to engage clutch

50", 60", & 72" 65 SERIES TILLER GEARBOX PARTS LIST


ITEM	PART NO.	DESCRIPTION	QUANTITY
	967558	Gearbox Assembly	
1	967395	Housing	1
2	967396	Hex Shaft	1
3	967397	Cover	1
4	967305	Snap Ring, 1.80, DIN 472	2
5	967398	Snap Ring Din 472/1	2
6	967399	Snap Ring Din 471/2	1
7	967400	Ring	As Required
8	967401	Ring	As Required
9	967402	Ring	As Required
10	967340	Ring, 85.2 x 94.7 x .3	As Required
11	967342	Ring, 85.2 x 94.7 x .5	As Required
12	967343	Ring, 85.2 x 94.7 x .2	As Required
13	967328	Ball Bearing 6012	1
14	966555	Ball Bearing 6208	1
15	967404	Cone & Cup Bearing	1
16	967330	Cone & Cup Bearing	1
17	967332	Oil Seal, 60 x 95 x 10	2
18	967405	Oil Seal	1
19	967312	Oil Plug, 3/8" DIN 906	3
20	967406	Gear Set	1



TL-34

82" 65 SERIES TILLER GEARBOX PARTS LIST

ITEM	PART NO.	DESCRIPTION	QUANTITY
	912300159	Gearbox Assembly	
1	967280	Housing	1
2	967323	Hex Shaft, 41.15mm Dia.	1
3	967281	Cover, 160mm Dia.	1
4	967325	Snap Ring E.45, DIN 471/2	1
5	967326	Snap Ring, I.95, DIN 472/2	2
6	967335	Ring, 45.2 x 54.8 x .6	As Required
7	967336	Ring, 45.2 x 54.8 x .8	As Required
8	967337	Ring, 45.2 x 54.8 x 1.0	As Required
9	967338	Ring, 45.2 x 54.8 x .3	As Required
10	967339	Ring, 45.2 x 54.8 x .4	As Required
11	967340	Ring, 85.2 x 94.7 x .3	As Required
12	967341	Ring, 85.2 x 94.7 x .4	As Required
13	967342	Ring, 85.2 x 94.7 x .5	As Required
14	967343	Ring, 85.2 x 94.7 x .2	As Required
15	967344	Ring, 85.2 x 94.7 x .1	As Required
16	967327	Ball Bearing, 6209	1
17	967328	Ball Bearing, 6012	1
18	967329	Cone & Cup Bearing, 30209	1
19	967330	Cone & Cup Bearing, 32012	1
20	967331	Oil Seal, 45 x 85 x 10	1
21	967332	Oil Seal, 60 x 95 x 10	2
22	967312	Oil Plug, 3/8" gaz. DIN 906	3
23	967334	Bevel Gear Set, R=1.192	1



SHIPPING KIT AND BUNDLE NUMBERS

The following is a list of Kit Numbers for this product and the Bundle Numbers, Descriptions, and Quantities for Each Kit.

QUANTITY	BUNDLE NO.	DESCRIPTION
C6550 50" Tiller c/w PTO		
1	F0857	Deck Assembly
C6560 60" Tiller c/w PTO		
1	F0859	Deck Assembly
C6572 72" Tiller c/w PTO		
1	F0861	Deck Assembly
C6582 82" Tiller c/w PTO		
1	F0863	Deck Assembly
C6550-4 50" Tiller 4-Tine c/w PTO		
1	F0858	Deck Assembly
C6560-4 60" Tiller 4-Tine c/w PTO		
1	F0860	Deck Assembly
C6572-4 72" Tiller 4-Tine c/w PTO		
1	F0862	Deck Assembly
C6582-4 82" Tiller 4-Tine c/w PTO		
1	F0864	Deck Assembly

The following is a list of options available for the Kits listed above.

OPTIONAL BUNDLE NUMBERS

902676 Adaptor Kit

NOTES

DIVISION LOCATIONS

Farm King Division
301 Mountain Street S.
Morden, MB R6M 1X7
Ph.: (204) 822-4467
Fax: (204) 822-6348

Allied/Inland Division
1260 Clarence Avenue
Winnipeg, MB R3T 1T2
Ph.: (204) 284-6100
Fax: (204) 477-2325

B.I.I. Division
1330 43rd Street N.W.
Fargo, ND 58102
Ph: (701) 282-7014
Fax: (701) 282-5865

U.S. WAREHOUSES

AR, West Memphis
(870) 732-3132

GA, Stone Mountain
(770) 908-9439

ID, Meridian
(208) 887-6006

IN, Clarksville
(812) 284-3376

KS, Wichita
(316) 265-9577

MN, Lakeville
(952) 469-5267

MT, Billings
(406) 248-7771

ND, Bismarck
(701) 223-1886

ND, Fargo
(701) 282-7003

NE, Blair
(402) 426-8211

OH, Youngstown
(330) 793-0862

OR, Beaverton
(503) 641-1865

SD, Huron
(605) 352-8616

TX, Houston
(713) 928-2632

UT, Salt Lake City
(801) 972-4321

WI, Portage
(608) 742-1370

CANADIAN WAREHOUSES

B.C., Abbotsford
(604) 864-2665

AB, Edmonton
(780) 962-6991

SK, Regina
(306) 781-2300

ON, Woodstock
(519) 539-0435

QC, Dorion
(450) 455-4840

OFFSHORE WAREHOUSES

Burando Hill
Katanning
W. Australia
011-618-98-214422

Chihuahua, Mexico
011-52-158-90306

John Kerr Equipment Ltd.
Wilcoxholm Farm
Linlithgow, W. Lothian
Scotland
011-441-506-842280

Skovde, Sweden
011-46-500-452651

Naestved, Denmark
011-45-557-29511

bühler

Buhler Manufacturing

**301 Mountain Street S.
Morden MB.
R6M 1X7
Ph.: (204) 822-4467
Fax: (204) 822-6348
www.buhler.com**